

# Description of ether examples YOTS

9/14/2018







# Agenda

- Software tools required
- → MII 10/100Mbps example
- $\rightarrow$
- $\rightarrow$
- $\rightarrow$






### **Installing software tools**

- Please install free software tools shown in below
  - Wireshark (<a href="https://www.wireshark.org/download.html">https://www.wireshark.org/download.html</a>)
  - python 2.7.X or 3.4+ (<a href="https://www.python.org/downloads/">https://www.python.org/downloads/</a>)
  - scapy (<a href="https://scapy.readthedocs.io/en/latest/installation.html">https://scapy.readthedocs.io/en/latest/installation.html</a>)







### **Description of this application**

- This example transmits/receives ether frames.
- In this example, TVII transmit ether packet back if it received ether packet.
- You can check transmitting/receiving ether frames using your PC with free software "Python Scapy" and "Wireshark".




#### Set up hardware (PSVP adaptor board)





Short TP211 and TP213



Close JP13, JP15, JP17





### Set up hardware (CYTVII-C-2D-500-BGA\_CPU\_BOARD)

- MII 100Mbps
  - Open R234 and R241
  - Close all related jumpers
- RGMII 1000Mbps
  - Open R234
  - Close all related jumpers



#### Set up hardware (CYTVII-C-2D-327-BGA\_CPU\_BOARD)

- MII 100Mbps
  - Open R234 and R241 and R235
  - Close all related jumpers
- RGMII 1000Mbps
  - Open R234 and R243
  - Close all related jumpers



#### Set up your PC

1. Open "Control Panel"->"Network and Internet"->"Network and Sharing Center" and click "Change adapter settings"












- 2. Right click on the LAN which is connected to the TVII board and click "Properties"
- 3. Click the "Configure" button 4. Select "Advanced" tab 5. Select "Speed and Duplex" in "Property" box
- 6. Select the speed you want (See next slide)







## Set up your PC

- MII 100Mbps
  - Select "100 Mbps Full duplex"
- RGMII 1000Mbps
  - Select "Auto Negotiation"



#### Modify the example and execute it


- Set the preprocessor macro "EMAC\_INTERFACE" "EMAC\_MII"
- Set the preprocessor macro "EMAC\_LINKSPEEP" in the C code so that the speed becomes as you like. (e.g. If you want to try 100Mbps, define "EMAC\_LINKSPEEP" as "ETH\_LINKSPEED\_100")
- If, you use "EMAC\_MII" and "ETH\_LINKSPEED\_100" and if you use PC, you have to disable auto MDI/MDI-X negotiation of the PHY.


- If you use "MII 100Mbps" with windows PC, search word "YOTS" in the code and uncomment the line to disable auto negotiation.
- Build your project and execute it.



#### Launch the "Wireshark"

- 1. Launch the "Wireshark" and select the LAN and make sure that the wireshark started capturing
- 2. Set the filter as "eth.src == 2.0.0.0.0.2 or eth.src == 4.0.0.0.0.4"







# Python scapy (find ether interface)

- launch command prompt.
- type "scapy"
- type conf.route and find your ether interface connected to the TVII

>>> conf.route					
Network	Netmask	Gateway	Iface	Output IP	Metric
0.0.0.0	0.0.0.0	10.13.56.1	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	35
10.13.56.0	255.255.248.0	0.0.0.0	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	291
10.13.56.60	255.255.255.255	0.0.0.0	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	291
10.13.63.255	255.255.255.255	0.0.0.0	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	291
127.0.0.0	255.0.0.0	0.0.0.0	Software Loopback Interface 1	127.0.0.1	331
127.0.0.1	255.255.255.255	0.0.0.0	Software Loopback Interface 1	127.0.0.1	331
127.255.255.255	255.255.255.255	0.0.0.0	Software Loopback Interface 1	127.0.0.1	331
192.168.1.0	255.255.255.0	0.0.0.0	<pre>Intel(R) Ethernet Connection (4) I219-LM</pre>	192.168.1.1	281
192.168.1.1	255.255.255.255	0.0.0.0	Intel(K) Ethernet Connection (4) 1219-LM	192.168.1.1	281
192.168.1.255	255.255.255.255	0.0.0.0	<pre>Intel(R) Ethernet Connection (4) I219-LM</pre>	192.168.1.1	281
224.0.0.0	240.0.0.0	0.0.0.0	Software Loopback Interface 1	127.0.0.1	331
224.0.0.0	240.0.0.0	0.0.0.0	<pre>Intel(R) Ethernet Connection (4) I219-LM</pre>	192.168.1.1	281
224.0.0.0	240.0.0.0	0.0.0.0	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	291
255.255.255.255	255.255.255.255	0.0.0.0	Software Loopback Interface 1	127.0.0.1	331
255.255.255.255	255.255.255.255	0.0.0.0	<pre>Intel(R) Ethernet Connection (4) I219-LM</pre>	192.168.1.1	281
255.255.255.255	255.255.255.255	0.0.0.0	Intel(R) Dual Band Wireless-AC 8265	10.13.56.60	291



#### Python scapy (Sending raw packet)

- create a raw ether packet instance. (>>> raw\_packet = Ether())
- set source MAC address (>>> raw\_packet.src = "2:0:0:0:0:2")
- set destination MAC address (>>> raw\_packet.dst = "4:0:0:0:0:4")
- set type (>>> raw\_packet.type = 0x0800)
- set payload (>>> raw\_packet.payload = Raw(load = "Hello")
- Send the packet (>>> sendp(raw\_packet, iface = "<your inaterface name>")

```
>>> raw_packet = Ether()
>>> raw_packet.src = "4:0:0:0:0:4"
>>> raw_packet.dst = "2:0:0:0:0:2"
>>> raw_packet.type = 0x0800
>>> raw_packet.payload = Raw(load = "Hello")
>>> sendp(raw_packet, iface = "Intel(R) Ethernet Connection (4) I219-LM")
.
Sent 1 packets.
```



#### Make sure transmitting/receiving frame

- 1. Your PC transmits the frame, destination address of which is "04:00:00:00:00:04"
- 2. Your PC receives the frame, destination address of which is "02:00:00:00:00:02"

